

Hose Clamp Tools



INSTALL/REMOVE ROTOR CLAMP HOSE CLAMPS WITH THESE DURABLE, QUALITY ENGINEERED TOOLS.

Pneumatic Hose Clamp Tools Helps Eliminate Carpal Tunnel Syndrome



Single Wire (HC/HW) Hose Clamp Pneumatic Tool (PWS)*

*Designations for individual HC sizes are listed on next page.



Double Wire (DW) Hose Clamp Pneumatic Tool (PWD)*

*Designations for individual DW sizes are listed on next page.

Constant Tension Band (CTB) Pneumatic Tool (PBC-1)** (Right)

**Specify PBC-1 for any Rotor Clamp CTB Hose Clamp you are installing. One size fits all.

PNEUMATIC TOOL FEATURES:

- Tangs of the clamp fit in the jaws of the tool and are compressed for installation or removal on the hose. Uses a compressed air line of 90 psi.
- Activated by a simple lever reducing stress on the hand from repeated assembly/disassembly.



Manual Hose Clamp Tools

For Ease Of Hose Clamp Installation/Removal



Single Wire Hose Clamp Plier (KC-18)

Install Rotor Clamp Single Wire (HC) hose clamps quickly and easily using this simple hand tool.

ONE SIZE FITS ALL. Specify KC-18 for any Rotor Clamp Single Wire (HC) hose clamp you are installing.

MANUAL TOOL FEATURES:

- Rugged Construction.
- Ease of Use.
- Designed for Efficiency.



Constant Tension Band (CTB) Hose Clamp Plier (HAZ-1)

A rugged, easy-to-use application tool for CTB hose clamps. Tool locks into place when clamp is fully compressed, relieving hand pressure when installing/removing. Tips can be adjusted to desired clamp opening to ensure fast, consistent installation or removal.

ONE SIZE FITS ALL. Specify HAZ-1 for any Rotor Clamp Constant Tension Band (CTB) hose clamp you are installing.



Constant Tension Band Light (CTL) Hose Clamp Plier (RPC-1)

These pliers are the recommended installation tool for CTL clamps. The RPC-1 is made of high carbon, heat treated steel and is produced to exacting QC specifications. The grips of these pliers are air cushioned and facilitate the effective and comfortable installation of CTL clamps.

Single Wire Hose Clamp Plier Heavy Duty (HAZ-2)

A heavy duty version of the Single Wire Plier, left. Tool locks into place when clamp is fully compressed, relieving hand pressure when installing/removing. Tips can be adjusted to desired clamp opening to ensure fast, consistent installation or removal.

ONE SIZE FITS ALL. Specify HAZ-2 for any Rotor Clamp Single Wire (HC) hose clamp you are installing.



Automatic Assembly Tools

Pneumatic Hose Clamp Tools for Automated Assembly

Pneumatic Single Wire Hose Clamp Tool



Rotor Clamp HC No.	Pneumatic Installation Tool	Rotor Clamp HC No.	Pneumatic Installation Tool
HC-4	PWS-4	HC-19	PWS-19
HC-5	PWS-5	HC-19.5	PWS-19.5
HC-5.5	PWS-5.5	HC-20	PWS-20
HC-6	PWS-6	HC-21	PWS-21
HC-7	PWS-7	HC-22	PWS-22
HC-7.5	PWS-7.5	HC-23	PWS-23
HC-8	PWS-8	HC-24	PWS-24
HC-8.5	PWS-8.5	HC-25	PWS-25
HC-9	PWS-9	HC-26	PWS-26
HC-9.5	PWS-9.5	HC-28	PWS-28
HC-10	PWS-10	HC-30	PWS-30
HC-10.5	PWS-10.5	HC-31	PWS-31
HC-11	PWS-11	HC-32	PWS-32
HC-12	PWS-12	HC-34	PWS-34
HC-13	PWS-13	HC-35	PWS-35
HC-14	PWS-14	HC-36	PWS-36
HC-15	PWS-15	HC-38	PWS-38
HC-16	PWS-16	HC-40	PWS-40
HC-17	PWS-17	HC-42	PWS-42
HC-17.5	PWS-17.5	HC-46	PWS-46
HC-18	PWS-18	HC-50	PWS-50
HC-188	PWS-188		

Pneumatic Double Wire Hose Clamp Tool



Rotor Clamp HC No.	Pneumatic Installation Tool	Rotor Clamp HC No.	Pneumatic Installation Tool
DW-4.5	PWD-4.5	DW-17	PWD-17
DW-5	PWD-5	DW-17.5	PWD-17.5
DW-5.5	PWD-5.5	DW-18	PWD-18
DW-6	PWD-6	DW-19	PWD-19
DW-6.5	PWD-6.5	DW-19.5	PWD-19.5
DW-7	PWD-7	DW-20	PWD-20
DW-8	PWD-8	DW-21	PWD-21
DW-8.5	PWD-8.5	DW-22	PWD-22
DW-9	PWD-9	DW-22.5	PWD-22.5
DW-9.5	PWD-9.5	DW-23	PWD-23
DW-10	PWD-10	DW-24	PWD-24
DW-10.5	PWD-10.5	DW-25	PWD-25
DW-11	PWD-11	DW-26	PWD-26
DW-11.5	PWD-11.5	DW-27	PWD-27
DW-12	PWD-12	DW-28	PWD-28
DW-12.5	PWD-12.5	DW-30	PWD-30
DW-13	PWD-13	DW-31	PWD-31
DW-14	PWD-14	DW-32	PWD-32
DW-14.5	PWD-14.5	DW-34	PWD-34
DW-15	PWD-15	DW-35	PWD-35
DW-16	PWD-16	DW-36	PWD-36

Please wear protective eyewear while installing and removing hose clamps.